


PARTS REPLACEMENT

EXPOSED THERMOSTATIC SHOWER SET



GUARANTEE & AFTERCARE

When installing or using tools, take care to avoid damaging the finish or fitting. Clean regularly with a soft damp cloth only to maintain appearance; avoid abrasive cleaners or detergents as they may cause surface damage. The company guarantees against faulty materials or manufacturing, excluding serviceable parts, if installed, cared for, and used according to our instructions.


WATER SUPPLY REGULATIONS

This product has been manufactured to comply with the relevant standards and conform to Water Supply Regulations.



PARTS REPLACEMENT

COMPONENTS LIST





636-1 086A 010-2 <u>398-07</u> <u>398-06</u> <u>398-11</u> 010-5 <u>398-07</u> 253-7 086WP-1A Ð 398-07 398-11 398-04A 010-1 398-11 010B 9086 0 398-04B -010-4 9089 1405 010-6 3418-1 694-1 0166-3 1831-1 6771A 277-1 3302 3416 Ø 3303 144-5 0 3303 332-18 0166-3 0 <u>365-4</u> 146-473 6771A 3418-1 146-470 3303 <u>245-1</u> 4407 3302 <u>313-1</u> 4238 1831-1 1405 219-3 2506 0 φ 817-1 219-4 245-1 4407 4238 1405 219-4 2507 219-3

PARTS REPLACEMENT

BILL OF MATERIAL				
ITEM	PT/ASSY	DESCRIPTION	TYPE	QTY
1	180-6	Shower Head	ASSEMBLY	1
	2440	Lookaut		1
2	3416	Locknut	ASSEMBLY	_
3	2014	Escutcheon	ASSEMBLY	2
4	1414	Screw	ASSEMBLY	2
5	086WP-1A	Brass Ferule	ASSEMBLY	1
6	694-1	Riser Pipe Faucet	ASSEMBLY	1
7	149B	Body	ASSEMBLY	1
8	398-06	Wall Mount Bracket	ASSEMBLY	1
9	180-2	Rubber Flat Washer	ASSEMBLY	1
10	398-04B	POM Clip	ASSEMBLY	1
11	2113	Handle-Hot	ASSEMBLY	2
	0166-3			
12		Wall Flange	ASSEMBLY	2
13	6771A	Comp nut	ASSEMBLY	2
14	3418-1	Brass Ferule	ASSEMBLY	2



